

GU-819-A A-Screen Screw
GU-819-R R-Screen Screw

GU-818-40 Filter Screen, 40 Mesh
GU-818-60 Filter Screen, 60 Mesh
GU-818-80 Filter Screen, 80 Mesh

GU-04007
Screen Screw Seal

OR-801
Back-up Ring

OR-800
O-Ring

OR-00043A
O-Ring

SP-04005
Spring

GU-817-90 Side Seal
GU-817-90D Side Seal, Delrin
GU-817-180 Side Seal, #3 #4

GU-816 Gun Block
GU-816S Gun Block Steel

GU-836
Side Mount Retaining Ring

TN-04186
Grease Fitting

GU-837
Retainer Ring Split-Set

OR-00042A
O-Ring

GU-830
Air Cylinder Bushing

GU-812
Lock Collar

GU-802
Piston

GU-807
Two Position Stop

OR-00026A
O-Ring

GU-804
Lock Knob

GU-831
Retaining Screw

GU-806
Spring

GU-803
Cylinder End Cap

OR-00043B
O-Ring

OR-00026A
O-Ring

OR-00043B
O-Ring

GU-801
Air Cylinder

OR-00037B
O-Ring

GU-829
A/P Check Valve

OR-804
O-Ring

OR-00002A
O-Ring

GU-824
Spool Valve Spring

GU-04019
Air Hose
(Not to scale)

GU-833
Hose Adapter

OR-803
O-Ring

GU-823
Spool Valve

GU-825-1
Spool Valve Liner

GU-825-2
Liner Bushing

GU-826
Air Manifold

GU-831
Retaining Screw

GU-827-1
Gun Handle

GU-828
Trigger

RA-00005A
A-Side Fitting

TN-04190
Shoulder Bolt

TN-04191
Nut

GU-808
Shoulder Bolt

GU-852
Check Valve Spring

GU-853
Check Valve Ball

GU-851
Check Valve Seat

OR-805
O-Ring

GU-808
Shoulder Bolt

GU-842
Head Latch

OR-805
O-Ring

RA-00006A
R-Side Fitting

GU-04001-01
Coupling Block Body

TN-04192
Plug

TN-04193 Small Mounting Bolt
TN-04197 Large Mounting Bolt

GU-023
Manual Valve Seat

GU-022
Manual Valve Housing

OR-015
O-Ring

OR-016
Back-up Ring

GU-021
Manual Valve Stem

GU-023
Manual Valve Seat

GU-022
Manual Valve Housing

OR-015
O-Ring

OR-016
Back-up Ring

GU-021
Manual Valve Stem

AP-2 Spray and Pour Gun

See Gun Manual for complete parts list.

